

**Granvista Plus Series
H.264 2-Megapixel
Outdoor Network Camera
GVP-221
User's Manual**



Version: 1.13

Revised April, 2012

Contents

Notices	2
Introduction.....	4
Installation.....	5
Using the Web UI.....	10
1. Live View	12
2. Video	14
General	14
Advanced	15
3. Camera	19
General	19
Advanced	21
4. Event	22
Event Server	23
Motion Detection	25
Event Configuration	26
5. Network.....	29
General	29
Advanced	30
SMTP (E-Mail)	32
DDNS.....	34
6. System.....	39
Information.....	39
User	40
Date & Time.....	41
Server Maintenance.....	41
Log Service	43
7. Customize	44
8. FAQ	46
Check firmware version	46
I/O Terminal Connector - Pin Assignment.....	47
Restore Factory Default	47
Upgrade device firmware.....	48
Video Streams Specification	49
The Angle of View at different resolutions	50
Appendix I: An example of how to set up users' own FTP servers	51
Appendix II: How to install the VLC program	60
Appendix III: How to replay the recorded video clips with VLC program	62

Notices

This user manual is intended for administrators and users of the GVP-221 IP66 Outdoor Network Camera, including instructions for using and managing the camera on your network. The use of surveillance devices may be prohibited by law in your country. It is the user's responsibility to ensure that the operation of such devices is legal before installing this unit for its intended use.

Before the Network Camera is installed, all the safety and operating instructions should be carefully read and followed to avoid damage due to faulty assembly and installation. This also ensures the product is used properly as intended.

Heed all warnings

- **Do not drop or strike this equipment**
Sensitive electronics inside the camera are vulnerable to excessive strike.
- **Do not install the equipment near any flames or heat sources**
Excessive heat could damage this equipment.
- **Do not cover cloth or to install this equipment in poorly ventilated places.**
Overheating could damage this equipment.
- **Do not damage the power cord or leave it under pressure**
Risk of fire or shock circuit
- **To reduce the risk of electric shock, do not remove the Cover (or Back).**
No user-serviceable parts inside. Misusage, improper, and negligence could damage this equipment. Need to refer servicing to qualified service personnel.
- **Do not continue to operate if it appears to be faulted.**
If the unit ceases functioning, contact qualified service personnel for help.
- **Any works related to detailed service or repair of this product should be made by qualified personnel only.**

Liability

Longvast International reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to Longvast International's terms and conditions of sale supplied at the time of order acknowledgment.

Longvast International is not responsible or liable for the resale of its products with statements different from or beyond the specification/parameters stated by Longvast International. Customers are responsible for their applications using Longvast International products. To minimize the risks associated with customer applications, customers should provide adequate operating safeguards. Longvast International is under no obligation to provide any further technical support service or product/software alteration beyond Longvast

International's representation.

Longvast International products are not authorized for use in safety-critical applications where a failure of the Longvast International product would cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use.

Reproduction of Longvast International information or datasheets with alteration is an unfair and deceptive business practice. Longvast International is not responsible or liable for any such statements.

Every care has been taken of with best efforts in this manual. If there are any inaccuracies or omissions, please inform your local office. Longvast International cannot be held responsible for any typographical or technical errors. Longvast International is not liable or responsible for incidental or damages caused by mishandling.

Trademarks

All names used in this manual for hardware and software are probably registered trademarks of respective companies. Granvista *Plus* is a registered trademark of Longvast International. All rights reserved.

Support

- If you require any technical assistance, please contact your Longvast International's regional resellers, and you may contact us too. Besides, you can connect to the Longvast International's Internet website of www.longvast.com for any updated information,

Introduction


Granvista Plus GVP-221 Outdoor Network Camera delivers superior H.264-AVC performance, state of the art design and function. GVP-221 is specifically adapted for maximum performance outdoor applications, such as commercial, banking, government buildings, schools, universities and airports.

H.264-AVC video compression can lower bandwidth and storage requirements without compromising image quality; Motion JPEG is supported for increased flexibility, as well as multiple independent video streaming.

GVP-221's value-added features include video-out jack for ease of angle adjustment at installation, on-board video motion detection and two-way audio. PoE is available, full PoE (IEEE-802.3af) feature supplies power to the camera via the network, eliminating the need for power cables, reducing installation costs and complexity. Therefore, GVP-221 is "Best in Class" for maximum performance IP video surveillance systems, demanding superior image quality, ease of installation, and intelligent video capabilities.


Installation

1. Hardware Connection



Remark: the video output is for angle adjustment purpose at installation site.

The user may use a hand-held monitor with BNC connector to connect to this video output port to easily adjust the view angle at installation.



Make both camera and PC connected to a local network through the RJ45 port. This camera supports PoE thus it can be powered by a PoE switch. If there is no PoE switch available then an 12V adapter will be needed to feed into the camera's power jack.

2. Software Installation

The following software is necessary for the proper display and use of the camera from the Web site. The software can be found in the Software Package CD.

IP Installer

The IP Installer is used to locate and configure Network Cameras on the LAN. This utility is useful for conveniently configuring the network settings of the device, or for finding a device once the network settings have been modified.

To install the IP Installer, from the Software Package CD folder, run the setup program from the IP Installer folder, and then follow the on screen instructions.

VLC

Though not necessary, this can be used for viewing the streaming without a Web browser. Besides, the VLC may be helpful in reviewing the recorded video files in the Micro SD card. Please refer to the appendix II & III for more details on how to install and use the VLC program.

XVID Codec

An H.264 codec is applied for displaying the video stream and playing the recorded AVI files. If the video stream can't be displayed, or the recorded AVI files can't be played on PC by using MPLAYER program, install this software from the Software Package CD. In other words, this XVID Codec allows users to replay the recorded files by using the Windows MPLAYER which many users are familiar with.

Network Configuration

IP Installer is a utility that provides an easier, more efficient way to configure the IP address and network settings of the devices. It even provides a convenient way to set the network settings for multiple devices simultaneously by using the batch setting function. Moreover, IP Installer can save the network settings for all devices as a backup and restore them when necessary. IP Installer is able to help non-professional users to quickly setup their network cameras to work in a professional manner.

Preparation before IP Assignment


1. Always consult your network administrator before assigning an IP address to your server in order to avoid using a previously assigned IP address.
2. Ensure the device is powered on and correctly connected to the network. This network can be simply a hub, PC and the network camera; and the network camera may directly connect to the PC too.
3. MAC Address: Each device has a unique Ethernet address (MAC address) shown on the label of the device as the serial number (S/N) with 12 digits (e.g. 000429-XXXXXX).



- Although the IP Installer is able to find and configure any Network Cameras in the LAN except those that are behind a router, it is a good idea to set the host PC to the same subnet. In order to connect to the Web-based user interface of the camera, the host PC must be in the same subnet. For more information about subnets, please consult your network administrator.

Using IPInstaller to Assign an IP Address to GVP-221

- Once IP Installer has been successfully installed on the PC, double click the IP Installer icon on the desktop, or select it from Start > Programs > IP Installer > Launch IP Installer.



- Click the “Device Search” tool bar and search the device in the LAN.

	Model Name	IP Address	MACAddress	Firmware	SubnetMask	Gateway	DNS1	DNS2	DNS3	Http Port
1	GVP-221	192.168.1.008	00-ab-cd-ab-cd-05	2.2.0_850_gvpma	255.255.255.0	192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	80
2	GVP-270	192.168.1.020	00-04-29-06-f8-ff	2.1.0215_gvpmb	255.255.255.0	192.168.0.254	168.95.1.1	61.31.1.1	61.31.233.1	80

Total 6 Devices



Please note that the firewalls of your Windows or Anti-virus software might block IP Installer from searching the cameras. In this case you would need to unblock IP Installer software from the firewalls, or to manually make this IP Installer software an exception to the firewalls.

- From the list, select the device with the MAC Address that corresponds to the device which is to be configured. The MAC Address is identical to the unit’s S/N (Serial Number).
- Right-click and select the “Single Device Setting” item to open the Property Page for the selected device.

	Model Name	IP Address	MACAddress	Firmware	SubnetMask	Gateway	DNS1	DNS2	DNS3	Http Port
1	GVP-221	192.168.1.008	00-ab-cd-ab-cd-05	2.2.0		192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	80
2	GVP-270	192.168.1.020	00-04-29-06-f8-ff	2.1.0		192.168.0.254	168.95.1.1	61.31.1.1	61.31.233.1	80
3	GVP-201	192.168.1.100	00-04-29-11-b6-01	2.2.0		192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	78
4	GVP-201	192.168.1.168	00-04-29-18-9b-01	2.2.0		192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	202

Total 6 Devices

- After filling in the properties, click [Set] button to complete the configuration settings in the remote device.



Example about how to know the user's PC and network information from command prompt. Simply type in "ipconfig" in the Command Prompt screen, press Enter, and you will see the related information which shows you the PC's IP, Subnet Mask, Default Gateway, etc.

The first three numbers of the network camera's IP must be same as the first three numbers of the PC's IP address, otherwise the screen can not be displayed properly on the WWW browser. In the above example the PC's IP address is 192.168.1.6., and we have set the camera's IP to be 192.168.1.8.

Open the Web-based UI of the Selected camera

1. To access the Web-based user interface of the selected unit by right-clicking and selecting "Open web" from the slide-bar.
2. If the device has been configured correctly, the default Web browser, the Internet Explorer, will open to the home page of the selected device.

3. If you find your browser is opened and automatically connected to the camera Home Page, it indicates that you've assigned an IP Address to the unit successfully. Now you can close the IP Installer and start to use your camera.
4. Usually the users no longer need to run the IP Installer software again after configuring the cameras correctly.

Device Search										
	Model Name	IP Address	MACAddress	Firmware	SubnetMask	Gateway	DNS1	DNS2	DNS3	Http Port
▶ 1	GVP-221	192.168.1.008	00-ab-cd		255.255.255.0	192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	80
2	GVP-270	192.168.1.020	00-04-29		255.255.255.0	192.168.0.254	168.95.1.1	61.31.1.1	61.31.233.1	80
3	GVP-201	192.168.1.100	00-04-29		255.255.255.0	192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	78
4	GVP-201	192.168.1.168	00-04-29		255.255.255.0	192.168.1.1	168.95.1.1	61.31.1.1	61.31.233.1	202
Total 6 Devices										

Verify and Complete the Installation from Your Browser


If not able to get the ActiveX downloaded properly, user must temporarily lower the security settings to perform a one-time-only installation of the ActiveX component onto the workstation, as described below:

- From the Tools menu, select [Internet Options] -> [Security] -> [Custom Level]
- Set the security level to Low and click [OK].
- Depends on different versions of browser software used, the users may have to set the individual ActiveX settings from "Disable" to "Prompt" or "Enable" if necessary for completing the ActiveX program downloads.
- Restore the security level after the ActiveX installation.



Using the Web UI

Start your Web browser and enter the URL or IP address in the Address field. The Home page of the camera is now displayed.



Note: Please do select “Run as administrator” to start the Internet Explorer browser if you are using Win-7 platform, otherwise you may not have the audio function to run properly.


How to make the Mozilla Firefox properly work with the cameras?

Please note that in addition to Microsoft Internet Explorer, other browsers such as Mozilla Firefox, Safari and Google Chrome are also compatible for viewing the screens from Granvista Plus network cameras. However, you may not be able to get full two-way audio supports from Firefox, Safari and Google Chrome due to the WWW browser software's existing support status on the needed plug-ins. If you want to have camera's audio feature with Firefox browser, you would have to install the needed plug-in from VLC.

Similar to Internet Explorer which needs to download the needed ActiveX programs, the Firefox browser will guide the users to download and install the VLC program for the needed plug-in the first time when it connects to the network cameras, so that it can work properly.



In the process of installing the VLC program, please be sure to check the "Mozilla plugin" option, so that Firefox may work properly with the network cameras.


The VLC program is a very handy shareware that the users will find it helpful when they want to replay the ".mp4" video clips recorded by the cameras. Actually the users may use its streaming function for viewing the camera's rea-ltime screen directly too. Please refer to the "Video/Advanced" introduction for more details.



Please note that the example here does not necessarily reflect to the latest version of VLC program.

1. Live View



Button	Description
	Click for more general/advanced camera settings
	Select languages among English, traditional Chinese, simplified Chinese and Spanish. If you like to add customized interfaces with other languages, please refer to the “How to add a new language into the user interface V.1.0.ppt” file in the CD for more details.
	Check actual size to view the actual size (resolution) of the image Image Setting: To adjust the brightness, hue and saturation

	<p>Choose among different streams for viewing. Due to bandwidth constraints the users may want to choose its 2nd video stream which is of 640x480 or 320x240. This 2nd stream supports digital PTZ function which users should find it helpful. There is a 3rd stream of fixed 640x480 resolution, and which is for 3G connection only @1fps.</p>
---	--



Button	Description
	Full screen
	Listen the audio input from site
	Talk function. An external speaker need to connect to its audio jack for audio output
	Record instant live video
	Snapshot the image

Further configurations and options; a prominent button in between is used to expand the further operations.



Click on the indicated prominent, and more operational options shows up.



2. Video

General

The screenshot shows a web interface for video settings. At the top, there are tabs: Live View, Video (highlighted), Camera, Event, Network, System, and Customize. Below these is a sub-panel with tabs for General (highlighted) and Advanced. The General tab contains two sections: 'Video General Setting' and 'OSD Setting'. Under 'Video General Setting', there are three checked checkboxes: 'Enable Stream 1', 'Enable Stream 2', and 'Enabled Digital PTZ'. Under 'OSD Setting', there are three checked checkboxes: 'Enable', 'Camera Name:', and 'Date/Time'. The 'Camera Name:' checkbox is followed by a text input field containing 'CH1' and a label '(20 character max)'. A 'Save' button is located at the bottom center of the page.

Video General Setting: Check each box to enable needed streams (max 3, including the 3rd one for 3G mobile phone) for live viewing.

Note: Digital PTZ is only available with stream #2. Please select the required video streams only, so that the system can be running at best performance. Stream #3 is not shown, because it is for 3G mobile phone connection only. It is transmitting at 1 frame per second / 320x240.

OSD Setting: Enable OSD (Over-Screen-Display) to display camera name or date/time on the image, the camera name must be a continual string, for instance "LivingRoom". This OSD setting may be set from the NVR too if any Granvista Plus series NVR has linked to this network camera.

Advanced

Stream 1 Setting	
RTSP Path:	v00
Image Format:	H.264
Resolution:	1600 x 1200
GOP:	15 (2~32)
Video Mode:	CBR
Frame Rates:	15 (5~15 FPS)
Target Bit Rates:	2000 (64~6000 Kb)


Stream 2 Setting	
RTSP Path:	v01
Image Format:	H.264
Resolution:	640 x 480
GOP:	30 (2~32)
Video Mode:	CBR
Frame Rates:	15 (5~15 FPS)
Target Bit Rates:	600 (64~6000 Kb)

Save

RTSP Path -

The RTSP (Real Time Streaming Protocol) Path is the stream ID used for RTSP client's streaming connection, such as VLC player or Blue Iris program. The default values are **v00** and **v01** for the two streams respectively. The string can be any combination of number or capital/small letters. It can not be empty however.


Following is a setting example of RTSP steaming by using VLC program. (The users may access this setup screen from VLC program's Media/Streaming.../Network). By way of defining the RTSP path names, the system administrator may control whoever may connect to whichever cameras inside the network.



Note: the “port number” of 556 in the example above is its RTSP port number which the user has defined for this camera (default value is 554). This port number must be routed in the network router properly if the user likes to receive the video streaming from the web. In other words, if the user likes to use the external web address of <rtsp://219.86.240.234:556/v00> in stead of the LAN address of <rtsp://192.168.1.99:556/v00>.

No.	Private IP	Private Port	Type	Public Port	Comment	Enabled
1.	192.168.1.99	91	Both	91	GVP-201	<input checked="" type="checkbox"/>
2.	192.168.1.99	556	Both	556	GVP-201	<input checked="" type="checkbox"/>

The example above is a setup screen of an Internet broadband router. In this example the port 91 is for WWW, and the port 556 is for RTSP. These two port numbers must be same as what configured in the camera’s Network/Advanced settings.



Note: the users may right-click and choose VLC program's "Full Screen" mode too.

Resolution -

The resolution here describes an image size counted by width and height, e.g. 640x480, referring to **pixel resolution**. The 1st stream can be set from more options of resolution; 1600x1200 (2 megapixels), 1280x720(HD), 800x600(SVGA), 640x480(VGA), 320x240(QVGA). While Stream2 has the options of VGA and QVGA, stream3 is in a fixed resolution, the VGA for 3G mobile phone. The users need to decide which resolution and frame rate options to be selected according to the requirements and practical constraints from the bandwidth and storage available.

Video Mode -

This option allows the selection of two bit-rate modes, the Constant Bit Rate (CBR) or Variable Bit Rate (VBR). CBR refers to the setting of a fixed **Target Bit Rate** (configuration in the range of 64Kbps to 6Mbps) that would apply in the case of limited bandwidth or/and storage requirement. While CBR concerns a fixed data rate transmitting, the video quality setting is of high priority for VBR mode selected. VBR therefore is configured with the **Quality Level** (Standard, Good, Best). In general, CBR predicts the provided condition; if image activity requires higher bit rates than configured, the frame rate and quality would be affected as not likely to increase bandwidth (bit rate). In spite of the required recording storage estimation, VBR is by way of compensation that adjustable bit rate fits the actual image activity.

Image Format -

H.264 and MJPEG are available for image format selection. The term, "image format", is referring to compression / encoding technique. The selection of image format decides the performance of bandwidth and

storage requirement. In the request of same video quality, H.264 contributes to less bandwidth and storage requirement, which is much more efficient than MJPEG. Therefore it is usually a better selection to select H.264 format if there is no particular reason for MJPEG.

GOP -

In MJPEG/H.264 video coding, GOP (group of pictures) describes how the different types of frames are arranged. The frame types implemented here are **I-frame** (full image information) and **P-frame** (motion-compensated difference information). This setting configures the **GOP length** which is the number of frames before next I-frame appears. Having more I-frames usually increases the stream size, and therefore more bandwidth and storage are required.

Frame Rates -

The Frame Rates defines the number of frames that will be displayed per second. The frame rate setting can affect the target bit rate (bandwidth requirement) and storage requirement.

The pre-configured frame rates can usually be fulfilled inside the local areas networks. However, it may not be able to be fulfilled for remote access, or if the network traffic is heavily loaded. For instance, if the camera has been configured to be 15 fps, the user most probably may see full 15 fps speed inside the LAN; however, the user might only be able to see 1-2 fps of video stream if he/she wants to connect from Internet remotely. The codes of the camera have been programmed this way that the camera will have to drop the P-frames inside its buffer on every connection session in case these queued P-frames still can not be sent out to the clients-side timely due to network traffic condition, in case the data buffer is close to be over-flown, so that the user can still see a lower-frame-rate, but still smooth enough video stream when network bandwidth is not sufficient.

Note:

While multiple streaming is possible, each stream has its limitation and dependency to other stream. See "**Video Stream Specification**".

3. Camera

General

Live View Video **Camera** Event Network System Customize

General Advanced



Camera General Setting

Brightness:	<input type="range" value="3"/>	3
Hue:	<input type="range" value="0"/>	0
Saturation:	<input type="range" value="100"/>	100
Contrast:	<input type="range" value="1"/>	1
Sharpness:	<input type="range" value="4"/>	4

Rotation 180

Web Record Setting

Save Path:
D:\temp\
File Name:
video

Web Snapshot Image Setting

Save Path:
D:\temp\
File Name:
snap

Camera General Setting:

Brightness: the luminance of image view

Hue: refer to pure a pure color, or described by its name, such as red, green or blue.

Saturation: intensity of a specific color

The 3 correlates are referring image appearance in terms of color/vision. These are adjustable from this page.

Rotation 180 degree: rotate the image, so it looks up-side down. This can be applied when camera unit must be mounted up-side down.

Audio Setting:

Enable this option, so the video stream will be transferring together with the audio data. There are two types of formats of AAC and G711. AAC takes less bandwidth, while its quality is fairly good already, but the users may still want to choose G711 if they want even better audio quality, and if there is no bandwidth and storage size concern.

AAC format must be selected if the users want audio to be recorded together with the video in Schedule or snapped web recording.

In case there is a Granvista Plus series NVR (network video recorder) available in the network for recording, the NVR will set G711 as its audio default.

Web Record/Snapshot Setting:

Web Record / Snapshot: define the locations where snapshot images and video clips will be stored. The file name is referring to the prefix of the file name of each snapshot image or video clip generated. These two settings' are saved in the Web Browser such as Internet Explorer, thus the settings will be reset if you reset the Web Browser software. Users may find it an easy cure to set it up in Windows's Safe Mode when they encounter problem with Vista platform which is stricter and more complicated in security settings than other platforms.

As to the "Web Recording Setting", if you have chosen D:\TEMP as the path and "video" as the file name prefix then the generated files will be saved into the D:\TEMP directory, and their file names will be in the format of "video" plus time tags, such as "video_20110102_121313_770". The "Web Snapshot Image Setting" is configured in the same way.

Default:

Set **[camera general setting]** and **[audio setting]** back to default

Note: As mentioned above, this Default command will not change the configuration of **[Web Record Setting]** and **[web Snapshot Image Setting]**

Save:

Save the changes which have been made

Advanced

Camera Advanced Setting

White balance: Auto

Exposure: Flicker-free 50 Hz

Max Exposure Time: 1/30 s

Max Gain Control: 31 dB

IR-Cut Filter (Enable=IR off, Disable=IR on): Auto

Light Sensor Day / Night Threshold: 20

Color/Mono Mode: Auto

Back Light Compensation: On

Video External Output Setting

Video External Output Format: PAL

Save

White balance: Adjustment to compensate for different environments in terms of light source.

Exposure: Anti-flicker setting for image sensor to fit the frequency of light (power) source. For instance, the power frequency is 50Hz for most European countries, while 60Hz is typically for US. This setting is therefore regionally different. **Note: Default setting is 50Hz**

Max Exposure Time: Referring to the shutter speed.

Max Gain Control: The maximum amplification factor for the incoming light. Similar to the photographic theories, in case of environment of dim light, increase it for optimal result if necessary. On the contrary, turn it down for environments of stronger light if necessary. Usually the users may leave it at max setting without the need to change for best results.


IR-Cut Filter (Enable=IR off, Disable=IR on): During the day time with sufficient light, the IR-Cut filter will be enabled to cover the lens so as to prevent the Infrared from coming in, therefore the image color will not turn red. During the night time or when the illumination has gone below the setting lux value, this IR-Cut Filter will be disabled (moved away from the lens), and the IR light will be turned on as supplementary light source. The users may adjust this on/off setting to manually control the IR light.

Light Sensor Day / Night Threshold: Adjustment for fine-tuning how dark to turn on the IR lights. The lower the setting, the darker it has to be to turn on the lights.

Back Light Compensation: Option for automatically making compensation for back light.

4. Event

Event handling describes the configurations of events and the corresponding actions. To have an insight into this function, a common example can be storing the captured images to FTP server or Email account (images only), or to activate the hardware output when there is an Event (hardware input, manual trigger, motion or periodic triggering).



The screenshot displays a web-based configuration interface for event handling. The main menu at the top includes 'Live View', 'Video', 'Camera', 'Event' (highlighted), 'Network', 'System', and 'Customize'. Under the 'Event' menu, there are sub-tabs for 'Event Server', 'Motion Detection', 'I/O Ports', and 'Event Configuration'. The 'Event Server' sub-tab is active, showing an 'Event Server List' table with one entry. Below the table are 'AddFTP..' and 'Remove' buttons, and a note stating '(Note: The maximum number of event servers is 10.)'.

Name	Protocol	Network Address	Upload Path	User Name
192.168.1.10	FTP	192.168.1.10	temp	ipcam

AddFTP.. **Remove**

(Note: The maximum number of event servers is 10.)

Event Server

The “Event Server List” lists the configured server(s) that will act as a remote storage or a destination for handling the triggered events. Up to 10 FTP servers can be added in the list.

(Note: The maximum number of event servers is 10.)

FTP Server

Name:

Network Address:

Upload Path:

Port:

Login Information

User Name:

Password:

Click on the **[Add FTP]** to expand FTP server setting

FTP Server:

- Name: Give a name for the FTP server.
- Network Address: Input the network address of the FTP server, which can be located in LAN or external web, for instance “192.168.1.100” or “219.86.240.234” respectively. Please note that such WEB IP such as “219.86.240.234” can be applicable only when the network is connected to Internet, and it is properly configured in the broadband router.
- Upload Path: Choose the desired upload path for events. If not specifically defined, it will be the default folder configured in the FTP system.
- Port: Input the port number of the FTP server, typically 21.

Remarks: FTP is quite a convenient web application, and it is quite easy to use. Attached below is an example of FTP screen indicates that a Network Camera keeps on talking to the FTP server. In this example the FTP server address can be set as either 192.168.1.3 (LAN) or 219.86.240.234 (WEB) from near end.

```
FileZilla Server version 0.9.44 beta
Copyright 2001 by Tim Kosse (Tim.Kosse@gmx.de)
Connecting to server...
Connected, waiting for authentication
Logged on
(000003) 2011/1/1 下午 15:08:32 - (not logged in) (219.86.240.234)- 421 Login time exceeded. Closing control connection.
(000003) 2011/1/1 下午 15:08:32 - (not logged in) (219.86.240.234)- disconnected.
(000004) 2011/1/1 下午 15:08:56 - (not logged in) (219.86.240.234)- Connected, sending welcome message...
(000004) 2011/1/1 下午 15:08:56 - (not logged in) (219.86.240.234)- 220-FileZilla Server version 0.9.44 beta
(000004) 2011/1/1 下午 15:08:56 - (not logged in) (219.86.240.234)- 220-written by Tim Kosse (Tim.Kosse@gmx.de)
(000004) 2011/1/1 下午 15:08:56 - (not logged in) (219.86.240.234)- 220 Please visit http://sourceforge.net/projects/filezilla/
(000004) 2011/1/1 下午 15:08:57 - (not logged in) (219.86.240.234)- USER home-1
(000004) 2011/1/1 下午 15:08:57 - (not logged in) (219.86.240.234)- 331 Password required for home-1
(000004) 2011/1/1 下午 15:08:58 - (not logged in) (219.86.240.234)- Pass *****
(000004) 2011/1/1 下午 15:08:58 - (not logged in) (219.86.240.234)- 530 Login or password incorrect!
(000004) 2011/1/1 下午 15:09:12 - (not logged in) (219.86.240.234)- TYPE I
(000004) 2011/1/1 下午 15:09:12 - (not logged in) (219.86.240.234)- 530 Please log in with USER and PASS first.
```

ID	Account	IP	Transfer	Progress	Speed
000004	(not logged in)	219.86.240.234			

Ready 37 bytes received: 0 B/s 315 bytes sent: 0 B/s

Login Information:

- Username / Password: Input the username and password of the FTP

Event Server List				
Name	Protocol	Network Address	Upload Path	User Name
192.168.1.10	FTP	192.168.1.10	temp	ipcam

(Note: The maximum number of event servers is 10.)

FTP Server	
Name:	<input type="text" value="192.168.1.10"/>
Network Address:	<input type="text" value="192.168.1.10"/>
Upload Path:	<input type="text" value="temp"/>
Port:	21

Login Information	
User Name:	<input type="text" value="ipcam"/>
Password:	<input type="password" value="*****"/>

Click **[Remove]** to delete selected event servers

Please refer to Appendix-I for more information on FPT applications.

Motion Detection

A snapshot image shows the whole view of the camera covered. To select a motion detection area, click directly on the image, and then change the size and position by dragging and drawing. Up to 10 motion areas (configurations) can be added in the list. Each detection area can be set with its own sensitivity value.

Live View Video Camera **Event** Network System Customize

Event Server **Motion Detection** I/O Ports Event Configuration

2-03-06 11:53:43

motion-trigger

Refresh

Motion Detection List

Windows	Area Name
	motion-trigger

Add Del

(Note: The maximum number of motion detections is 10.
Set New Motion Detection Area :
1. Click 'Add' and rename the windows area.
2. Drag a detection area on the image.)

Motion Detection Setup

Windows Area Name: motion-trigger

Trigger Level : 16

Sensitivity : 17
(Sensitivity value:0~100[low~High])

Color: #FF0000

View All Windows
 View Selected Window

Save

Event Configuration

The Event Configuration is to assign the actions responding to the specified events (Trigger Conditions). The table lists the configured events. Click on “**Add...**” or choose an event from the list to expand the panel for detail configurations. “**Remove**” is to delete a selected event.

The screenshot shows the 'Event Configuration' interface. At the top, there are 'Add...' and 'Remove' buttons. Below them is a note: '(Note: The maximum number of events is 10. Fu=FTP Upload, Eu=Email Upload, Du=Disk Upload, O=Output Port, En=Email Notification, Hn=HTTP Notification, Tn=TCP Notification.)'. The main section is titled 'Event Type Setup'. It contains a 'Name:' field with 'NewEvent' entered. Below it is 'Set min time between trigger:' with '00:00:00' and '(max 23:59:59)'. The 'Respond to Trigger' section has three radio buttons: 'Always' (selected), 'During time between' (with day selection: Sun, Mon, Tue, Wed, Thu, Fri, Sat), and 'Never'. Below these are 'Start Time:' and 'Duration:' fields. The 'When Triggered...' section has a checked checkbox for 'Upload Images' and a dropdown menu showing 'FTP', 'Email', and 'Disk'. Other unchecked options are 'Activate Output Port', 'Send Email Notification', 'Send HTTP Notification to', and 'Send Message Notification (TCP)'. At the bottom, there is a 'Save' button.

1. To add an event trigger, click on [Add] and setup panel will be expanded.
2. Give a name to this event.
3. Set the time interval between each trigger.
4. Set the time period for the trigger. Choose “Always” or “During time between” or “Never”.
5. The trigger condition is Motion Detection.

The responding actions can be “Upload images” and “Activate Output Port” and “Send Email Notification” and “Send HTTP Notification to” and “Send Message Notification (TCP)”.

6. Click on [Save] to save the configuration made

Besides, the users may use the free-bundled Network Recording Software for data storage and playback. This software can be found in the CD. Network Recording Software may connect up to 36 channels, and it may satisfy all the typical requirements the users may have. Please refer to its manual for more details.

The users may also take advantages of our Linux-based Granvista Plus NVR for even more advanced and professional applications. Up to 64 connections, or even more, are able to be built into the Granvista Plus series NVRs. Please refer to our web site, or contact us for more details. Attached below is a sample of our SOHO model NVR which may support up to 6 connections.




Up to 6 cameras connectivity capacity



For best pricing competitiveness and SOHO NVR hardware's optimal after-sales services, strategically we allow our regional partners to only purchase the software which is stored in DOM (disk on module) from us, and to purchase and assembly the hardware locally.

Granvista Plus NVR / CMS Network Diagram – for users' advanced requirements



5. Network

Network Camera acts as one of the network devices. It therefore allows its “IP” to be assigned, so certain network functionalities can be implementable within this device. This section describes these configurations. Fundamentally, for instance, the IP assignment of the device can be done via **DHCP server**, **manually fixed IP option** or **PPPoE** to obtain IP from service provider.

General

Device IP configuration, includes DHCP, Static IP setting and PPPoE. “Enable ARP/Ping” enable device to accept ARP or ping packets from the network. Disable this option may provide extra security from intentional ping.

The screenshot displays a web-based configuration interface for a Network Camera. The top navigation bar includes tabs for Live View, Video, Camera, Event, Network (highlighted in red), System, and Customize. Under the Network tab, there are sub-tabs for General (selected), Advanced, SMTP(E-Mail), and DDNS. The General tab contains the following configuration options:

- DHCP Service
- Static IP Address:
 - IP Address: 192.168.1.8
 - Netmask: 255.255.255.0
 - Gateway: 192.168.1.1
 - DNS 1: 168.95.1.1
 - DNS 2: 61.31.1.1
- PPPoE:
 - User Name: username
 - Password:

(Note : Please make sure 'Email Setting' has been set!)

Enable ARP/Ping

Save

Advanced

Enable or configure other network functions.

The screenshot shows a web interface with a top navigation bar containing tabs: Live View, Video, Camera, Event, Network (highlighted in red), System, and Customize. Below this is a sub-navigation bar with tabs: General, Advanced (highlighted in blue), SMTP(E-Mail), and DDNS. The main content area is titled 'Advanced' and contains several configuration sections:

- NTP Configuration:** Two radio buttons are present. The first is 'Obtain NTP server address via DHCP' (unselected). The second is 'Use the following NTP server address:' (selected). Below this, there is a text input field labeled 'Network address:' containing 'time.stdtime.gov.tw'. A note below the field says '(host name or IP address)'.
- HTTP Setting:** A text input field labeled 'HTTP Port:' contains '80'. To its right, the text '(0 ~ 65535, Default : 80)' is displayed.
- RTSP Setting:** A text input field labeled 'RTSP Port:' contains '556'. To its right, the text '(0 ~ 65535, Default : 554)' is displayed.
- Bonjour Setting:** A checked checkbox is followed by the text 'Enable Bonjour'.
- UPnP Notification:** A checked checkbox is followed by the text 'Enable UPnP'.
- NAT Traversal Setting:** An unchecked checkbox is followed by the text 'Enable NAT Traversal'.

At the bottom center of the configuration area is a 'Save' button.


NTP: Configure a NTP (Network Time Protocol) server, so that the device system date and time can be synchronized with a specified Time Server. This configuration is provided for one of the portions of system date/time adjustment. If the camera is located in an isolated LAN, in other words it does not have access to web, the user may set the IP of the PC in LAN as its NTP setting, so that the camera's time will be synchronized with the PC.

HTTP: set the HTTP port that will be applied for Web UI access. The default port number of HTTP is "80", but it can be of other figures.

RTSP: set the RTSP (Video) port for video data transmission. The default port number of RTSP is "554", but it can be of other figures.


Bonjour: Enable Bonjour service, so that the device can be discovered with “Bonjour” service applied.

UPnP: Enable UPnP, so that the device can be discovered in an UPnP Compliant Network.



NAT Traversal: Enable NAT traversal, so that client from Internet can have access to the devices behind the Router. If user would like to access the Network Camera from Web externally, be sure to also include the RTSP port by duplicating the same IP.

In the following example this Network Camera’s LAN IP is of 192.168.1.2., thus the user should type in the full address of <http://192.168.1.2:80> (as port 80 is WWW’s default port number thus “:80” can be omitted) in the address field of Internet Explorer to access this network camera. If the user wants to access it from web externally, he would have to properly setup its HTTP port (in this case “80”, or other port number), and the RTSP port (in this case “554”, or other port number) in the NAT setting of the router beforehand, and then he may access it with the web address (in this example it is <http://219.86.240.234:80> to access it from anywhere of the world via Internet) if the router has connected to Internet.



Note: with UPnP enabled, the IP Sharing device (Router) capable of UPnP function will automatically be noticed with the device’s NAT port.

SMTP (E-Mail)

Configure an email host in the device that will send email on behalf of the configured email account in a circumstance like sending an email notice to a specified mail address (Event Configuration), or to send the triggered image. The email settings will be basically same as what used in your email software.

Mail server: The SMTP server (for out-going emails). Please refer to your ISP to get the right Mail server and port number information.

User Name and Password: Complete the Mail Server, Server Port, Authentication information (if required) and the sender's email address.

From (Email Address): What to be shown as the sender when the email is received. **It does not necessarily need to be a real email account.** In this example the test@longvast.com actually does not exist. For instance, the user may define cam1@longvast.com, cam2@longvast.com, or cam3@longvast.com, etc, which do not exist to specify different cameras by sending from the same ipcam2@longvast.com email account.

Send email to: The recipient email address

Following screen shows an example of setting an email account. The users may need to refer to the ISP for more details on the email configuration. In this example the ipcam2@longvast.com Email account will be used to send triggered images or notifications to the info@longvast.com account.

The screenshot shows the 'SMTP(E-Mail)' configuration page. The 'SMTP (email) Setting' section includes the following fields and annotations:

- Mail Server:** (host name or IP address). Annotation: "The SMTP server of the mail service".
- Server Port:** [0..65535]. Annotation: "Port number of the mail server, must be set correctly".
- Authentication**
- User Name:** . Annotation: "Email and password of this email account to be used".
- Password:**
- From (Email Address):** . Annotation: "What to be shown as the sender when the email is received."
- Send email to:** . Annotation: "The recipient email account".


Buttons: "Test" (bottom right), "Save" (bottom center).

If the setting is successful, click on "Test" button, and then an acknowledgement email with "Email Test OK" message should be received by the recipient immediately. Following is an example of such acknowledgement email after clicking "Test" button.

The screenshot shows an email client interface with the following details:


- Current Folder: **INBOX**
- Compose | Addresses | Folders | Options | Search | Help
- Message List | Unread | Delete | Previous | Next
- Subject:** Email Test
- From:** test@longvast.com
- Date:** Mon, September 26, 2011 10:11 am
- To:** info@longvast.com
- Priority:** Normal
- Options:** [View Full Header](#) | [View Printable Version](#) | [Download this as a file](#)

Email Test OK



Remark:

1. Similar email of the above example can be received at the camera's starting-up or being reset, if the SMTP settings are correctly configured and the camera is connected to the Internet. It notifies the user what's the camera's current IP address. It is helpful for users to locate the IP of camera when using DHCP or PPPoE network setting.
2. Please also refer to the description of the Network/General setting paragraph inside this manual, note that in the example of the above image the "192.168.1.100" indicates to be a LAN address. However, in the case that the users are able to get real IP from Internet Service Provider, the camera may get a real Internet IP after correctly making the PPPoE setting, and in this case instead of getting a LAN IP such as "192.168.1.100", a real Internet IP such as "219.86.240.230" will be shown in the above email notification.



DDNS

Dynamic DNS configuration; the network device can be assigned and accessed with a host name instead of IP address by registering this service (Internet access required).

Host Name: Assigned name that will be used for access to the device

User Name/Password: Account authentication for logging to this service

Update Time: Periodically, the device updates its access info to sever in the configured time.

Response: the device responds the connection info.

Following illustrative contents show the users some details about applying DynDNS service. Please note that DynDNS is not the only service available in the world market for DDNS services. Besides, DynDNS provides free services, and they also provide advanced services which are non-free.

DynDNS.com by Dynamic Network Services Inc.

Username Password
[Lost Password?](#) [Create Account](#)

About Services Account Support News

I'd like to...

- [Remotely access my home computer](#)
- [Control my DVR from anywhere](#)
- [Get a free domain name](#)
- [Safeguard my email](#)
- [Protect and speed up my Internet](#)

Introducing the NEW
DynDNS Community
An all new format to help you get the absolute most out of DynDNS.com and help others do the same.

- Community voting on Questions/Answers
- Reputation Points and Service Badges
- Single Sign on for DynDNS.com Users

Free Dynamic DNS

Point a hostname to a dynamic or static IP address or URL.

- Host your own website at home for free!
- Connect to your workstation, DVR, webcams from anywhere.

example .dynDNS.biz

» DDNS service details...

DNS Hosting & Domains

Register **your domain** and point it to an IP address or URL

- Easy-to-use web interface with powerful expert tools.
- Secondary and primary DNS servers around the globe!

example.com

» more about Custom DNS hosting...

Resources

- [What is DNS?](#)
- [DNS Tools](#)
- [Home DNS Solutions](#)
- [Business DNS Solutions](#)

Services

- [DNS Hosting](#)
- [Free Dynamic DNS](#)
- [Spring Server VPS](#)
- [Domain Registration](#)

Support

- [DynStatus](#)
- [Knowledge Base](#)
- [24/7 Premier Support](#)
- [DNS Update Clients](#)

Follow Us

- [Our News](#)
- [Twitter @dyninc](#)
- [LinkedIn](#)
- [DNS Ninjas | Facebook](#)

This series network device support DynDNS (www.dyndns.org). This section describes how to apply this service to the Network Camera.

Create Account

Create an account or log in to continue

Username:

Password:

Confirm password:

Email:

Confirm email:

Subscribe to: DynDNS.com newsletter
(1 or 2 per month)
 Dyn Inc. press releases
 Remove HTML formatting from email

Security Image:

Enter the numbers from the above image:

I agree with the [acceptable use policy \(AUP\)](#) and [privacy policy](#).

If you're having difficulty creating your account, for any reason, feel free to [contact us](#).

Already Registered?

Username

Password

[Forgot your password?](#)



Input user name, password and Email that will be created as an account for logging in the service. .

The website has accepted the new account and sent email for verification.

In the received mail from DynDNS, use the link to activate. The account will then be confirmed as the web below shows.

NS.com
Network Services Inc.

Username Password

[Lost Password?](#) [Create Account](#)

About Services Account Support News

Account Confirmed

The account `pixord-ddns` has been confirmed. You can now [login](#) and start using your account.

Getting Started

- [Surf without the sharks and browse the web faster with Internet Guide](#)
- [Create a dynamic DNS host with your own domain name](#)
- [Create a dynamic DNS host within our Free domains](#)
- [Setup email services](#)
- [Register a domain name](#)



© 1998-2010 [Dynamic Network Services Inc.](#) - [Legal Notices](#) - [Privacy Policy](#) - [Contacts](#)



Login and use the service

Username Password

[Lost Password?](#) [Create Account](#)

Home Support News

In the login field, input username and password as the new account created.

My Services

 View, modify, purchase, and delete your services.

- [My Zones/Domains](#)
 - [Add Zone/Domain Services](#)
- [My Hosts](#)
 - [Add Host Services](#)
- [Dynamic DNS Pro](#)
- [Internet Guide](#)
- [Spring Server VPS](#)
- [MailHop Outbound](#)
- [Network Monitoring](#)
- [SSL Certificates](#)
- [Recursive DNS](#)
- [Support](#)
 - [Premier Support](#)
 - [Contact Support](#)
 - [DNS Service Level Agreement](#)

After logged in, in the **“My Services”** column, click on **“Add Host Services”**.

Fill in a host name as it will be applied to the device. The **“IP Address”** field can be temporarily filled with any IP as it will be updated once the device has registered to the service and reported its current IP value. Click on **“Add To Cart”** for next stage. The Dynamic DNS host service is free. Just click on **“Next”**.

Checkout from the applying service and activate the added host name.

The information of activated host name will be arranged. Click on **“Add New Host”** if requiring more host names for other Network Cameras.

Apply Host Name to the Camera

Dynamic DNS Setting

DDNS Enable

Host Name: (Link to <http://www.dyndns.org>)

User Name:

Password:

Update Time: (600~86400 Seconds)

Response:

Your domain name

The account user name and password with DYNDNS

It will show "yes" if this DDNS service is operational

Click Save to see if the setting is valid

In the device configuration page, Setup -> Network -> DDNS, fill in the applied host name from DynDNS website, the username / password that are for logging in this service. Enable DDNS, and then save the settings. The "Response" will show "yes" message when registering is successful.



Launch IE and type <http://granvistaplus.dyndns-ip.com/> (for instance) in the URL filed. The page should be directed to the device's live view page. Please note that the address of <http://granvistaplus.dyndns-ip.com/> is equivalent to the address of <http://granvistaplus.dyndns-ip.com:80/>, because the default WWW port number is 80.

In this example the address of <http://granvistaplus.dyndns-ip.com/> is same as <http://219.86.240.234/>. Please refer to the Network setting paragraph in this manual, the user must properly setup the HTTP and RTSP ports in both camera and broadband router's NAT virtual domain settings to make sure camera can be accessed by the address of <http://219.86.240.234/> before the <http://granvistaplus.dyndns-ip.com/> address is able to work properly.

How if the user has only one fixed web IP, for instance 219.86.240.234, while he has many network cameras to implement?

Just like the user may setup the camera address of <http://219.86.240.234:91/>, <http://219.86.240.234:92/>, etc, the address of similar setting of <http://granvistaplus.dyndns-ip.com:91/> or <http://granvistaplus.dyndns-ip.com:92/> can be configured for other network cameras too. Following figure is an example of such DDNS application by using specific port number.



Users may find this DDNS function useful when they do not have fixed IP available. For instance, some Internet Service Providers do not provide fixed IP, and the IP available could be the ones generated randomly after completing login processes through PPPoE protocol. As under such circumstances the users do not know what IP will be generated, therefore they can just keep using the fixed domain names from the DDNS service, as long as the DDNS service has been configured properly.

For this application, following are the procedures:

1. Configure the DDNS settings properly when the IPCAM is running under DHCP or fixed-IP networking mode, make sure that a “yes” status is seen from the DDNS setup page of the IPCAM after clicking “save”.
2. Check if the domain name is valid and working by typing in the domain name in the address field of the WWW browser. For instance, type in “<http://granvistaplus.dyndns-ip.com/>” in the address field of IE browser to see if it may connect to the IPCAM properly after configuring the DDNS settings.
3. Go to Setup/Network/General setting page of the IPCAM’s user interface, and change the network protocol to PPPoE. Save the settings, and reset the IPCAM by switching the power.
4. Check to see if the IPCAM can still be located and connected by the address of the configured domain name of “<http://granvistaplus.dyndns-ip.com/>”.

Note:

Please note that the IPCAM will send back an email to tell the user of its new IP address after it has successfully logged into a network, in case the email settings have been properly configured, and if the camera is connecting to the Internet. The users may also keep track of the new IP addresses from such email feedback.

6. System

Information

Lists of System and Network configurations

The screenshot shows a web interface with a top navigation bar containing tabs: Live View, Video, Camera, Event, Network, System (selected), and Customize. Below this is a sub-navigation bar with tabs: Information (selected), User, Date & Time, Server Maintenance, and Log Service. The main content area is divided into sections:

- System**
 - Model: **GVP-221**
 - System up time: **2012-03-05 11:46:16**
 - Firmware version: **2.2.0_850_gvpma**
 - MAC Address: **00:ab:cd:ab:cd:05**
 - ActiveX Control version: **1.0.1.151**
- Ethernet**
 - Status: **Connected**
 - Mode: **STATIC**
 - IP Address: **192.168.1.8**
 - Netmask: **255.255.255.0**
 - Default Gateway: **192.168.1.1**
- PPPoE**
 - Status: **No connection**
 - IP Address: **none**
- DNS Server**
 - Primary DNS IP address: **168.95.1.1**
 - Secondary DNS IP address: **61.31.1.1**
- DDNS**
 - Status: **no**

User

Login users for Web access and operations; authentication required. The Check box is for anonymous logging to the live view page.

Please be sure not to select the anonymous login unless convenience is more important than privacy.

Logging for further configurations will still require user name and password even if anonymous login has been selected. Please note that maximum lengths of user name and password are 14 and 8 respectively.

The authorities of different levels of users are as follows:

Administrator:

Allowed to do any adjustments in camera, is the default user that this account can't be deleted.

Operator:

Allowed to view the live video and change Video & Camera settings in Setup Menu only. (Live View, Video & Camera settings in setup menu)

Viewer:

Only permit to watch the live video, can't get into the Setup Menu. (Live View only in setup menu)


Date & Time

System date/time configuration. Options of synchronizing with PC and NTP server are provided for automatic adjustment in addition to manual setup.


The screenshot shows a web interface for system configuration. At the top, there are tabs for 'Live View', 'Video', 'Camera', 'Event', 'Network', 'System', and 'Customize'. The 'System' tab is selected. Below it, there are sub-tabs for 'Information', 'User', 'Date & Time', 'Server Maintenance', and 'Log Service'. The 'Date & Time' sub-tab is active. The main content area is divided into two sections: 'Current Server Time' and 'Set Server Time'. The 'Current Server Time' section shows 'Date: 2012-03-07' and 'Time: 13:46:07'. The 'Set Server Time' section has a 'Time Mode:' label. There are two radio buttons: 'Synchronize with computer time' (unselected) and 'Synchronize with NTP server' (selected). Below the 'Synchronize with NTP server' option, there are 'Date: 2012-03-07' and 'Time: 13:46:16' fields. A 'Time zone:' label is followed by a dropdown menu showing 'GMT+08 (Beijing, Hong Kong, Shanghai, Taipei)'. Below this, there is a 'Set Manually' radio button (unselected). Underneath, there are 'Date: 2012-03-07' and 'Time: 13:46:07' fields. Below the date field, there is a note '(ex: 2008-01-01)'. Below the time field, there is a note '(ex: 01:00:00)'. At the bottom of the form, there is a 'Save' button.

Server Maintenance

This page provides tool for system maintenance; Reboot and Load default settings, as well as functionalities of launching upgrade process, backup/restore user settings and language defines.




If you like to add customized interfaces with other languages, please refer to the “How to add a new language into the user interface V.1.0.ppt” file in the CD for more details.



Log Service

Most system operations and / or process will be kept in a log system. The link provides the review of these records.



7. Customize

This page provides the function of adjusting the look of live view page. There are two types of layout settings; use default look or use custom settings.

The screenshot shows a web interface with a navigation bar at the top containing tabs for 'Live View', 'Video', 'Camera', 'Event', 'Network', 'System', and 'Customize'. The 'Customize' tab is selected and highlighted in red. Below the navigation bar is a section titled 'Live View Layout Setting' with two radio buttons: 'Use Default Look' (selected) and 'Use Custom Settings'. Below this is a section titled 'User Defined Links' containing four rows. Each row has a checkbox labeled 'Show Custom Link' followed by a 'Name' field and a 'URL' field. The 'Name' fields contain 'Custom Link 0', 'Custom Link 1', 'Custom Link 2', and 'Custom Link 3' respectively. The 'URL' fields all contain 'http://'. At the bottom center of the form is a 'Save' button.

Live View Layout Setting	
<input checked="" type="radio"/> Use Default Look	<input type="radio"/> Use Custom Settings
User Defined Links	
<input type="checkbox"/> Show Custom Link 1	
Name: Custom Link 0	URL: http://
<input type="checkbox"/> Show Custom Link 2	
Name: Custom Link 1	URL: http://
<input type="checkbox"/> Show Custom Link 3	
Name: Custom Link 2	URL: http://
<input type="checkbox"/> Show Custom Link 4	
Name: Custom Link 3	URL: http://

Save

Use Default Look: the default layout of live/configuration pages

Use Defined Links: Web link(s) will be presented on the live page when enabled. It can be a link to another Network Camera for instance, or other preferred web link.

Use Custom Settings: The modifications allowed are changes of Background / Text Color, Background picture, Title, Description, Logo and etc.

Live View Layout Setting

Use Default Look Use Custom Settings

User Defined Links

Show Custom Link 1
Name: Custom Link 0 URL: http://

Show Custom Link 2
Name: Custom Link 1 URL: http://

Show Custom Link 3
Name: Custom Link 2 URL: http://

Show Custom Link 4
Name: Custom Link 3 URL: http://

Custom Settings

Modify the Default Look:

Background Color: Default Own: White

Text Color: Default Own: Black

Background picture: None External: http://

Title: None Default Own: Title

Description: None Default Own: Description

Logo Link: None Default Own: http://


Logo: None Default External: http:// Own

Select image file to upload:

8. FAQ

Check firmware version

The version code can be found in Setup -> System -> Information, or simply type "version.html" after the URL address, e.g. <http://192.168.1.8/version.html>. Firmware version indicates the functionalities' updates or availability in the camera system. Therefore, in the first step of troubleshooting and then reporting, it helps to locate the found issues. Newer version firmware may have corrected the current bugs.




The screenshot shows a web interface with a top navigation bar containing tabs: Live View, Video, Camera, Event, Network, System (highlighted), and Customize. Below this is a sub-navigation bar with tabs: Information (highlighted), User, Date & Time, Server Maintenance, and Log Service. The main content area displays system information in a table format:

System	
Model:	GVP-221
System up time:	2012-03-05 11:50:00
Firmware version:	2.2.0_850_gvpma
MAC Address:	00:ab:cd:ab:cd:05
ActiveX Control version.:	1.0.1.151



The screenshot shows a Windows Internet Explorer browser window titled "loading - Windows Internet Explorer". The address bar contains the URL "http://192.168.1.8/version.html". Below the address bar, the text "2.2.0_850_gvpma" is displayed.

I/O Terminal Connector - Pin Assignment



Restore Factory Default


To restore factory default, please follow the steps:

3. Unplug the power jack to turn off the camera
4. Short pin 5 and pin 6 with a wire
5. Plug in the power jack to turn on the camera. The power LED will start flashing in a short while.
6. Break the short when the LED starts quick flashing. Wait for a few minutes the device should be set back to factory default.

Upgrade device firmware

Firmware upgrade process should be done via the web configuration; **Setup -> Server Maintenance -> Firmware Upgrade**. Before the process, read the instructions and release notes coming with each new released version. For the steps,

1. Check and retrieve the latest firmware bin file.
2. Disconnect all other clients (e.g. streaming requests) to the device.
3. Stop the local (schedule) recording if it was enabled.
4. Go to the Firmware Upgrade page, browse and locate the downloaded firmware bin file, then click on “Upgrade” button.




The screenshot shows a web interface titled "Maintain Server". At the top, there are two buttons: "Reboot" and "Load default". Below this is a section titled "Firmware Upgrade". It displays the following information:

Model:	GVP-221
Firmware Version:	2.2.0_850_gvpma
MAC Address:	00:ab:cd:ab:cd:05
ActiveX Version:	1.0.1.151

Below the table, there is a label "Specify the firmware to upgrade:" followed by a text input field and a "Browse..." button. At the bottom right of this section is an "Upgrade" button.

5. The upgrade should finish in minutes, depending on file transferring status. The web will then be directed to the system writing progress. Overall upgrading process takes about 5~10 minutes. In this period, **DO NOT DISCONNECT the power and Ethernet connection** while the upgrade is in progress, otherwise software of the unit can be damaged.



6. Check the firmware version. If somehow system is not upgraded, redo above steps. In this case, restore factory default process may be required.

Video Streams Specification

The availabilities

1. Each stream can be switched to either H.264 or MJPEG mode.
2. Each steam can be configured to either CBR or VBR mode.
3. Stream1 (main stream) is available from all the resolutions listed.
4. The maximum resolution setting for Stream#2 is 640x480.
5. Stream#3 is fixed in 640x480 for 3G mobile phone which is not shown on user interface.
6. The maximum frame rate for transferring 1600x1200 is 15fps. Others can reach up to 30fps.

	STREAM #1	STREAM #2	STREAM #3
Encoding Mode			
<i>H.264 / MJPEG</i>	V	V	
Transferring Mode			
<i>CBR / VBR</i>	V	V	
Resolution @ Max. FPS			
<i>1600x1200@15</i>	V		
<i>1280x720@30</i>	V		
<i>800x600@30</i>	V		
<i>640x480@30</i>	V	V	
<i>320x240@30</i>	V	V	640x480 @1 fps

Dependency


1. **Max. FPS dependency:** when **Stream #1** is set to **1600x1200**, the maximum frame rate is **15fps**.
2. **Resolution dependency:** The maximum resolution of **Stream #2** is depending on the resolution setting of **Stream #1**. When Stream1 is set to 320x240, Stream 2 is limited to 320x240.
3. **Frame rate independent:** Frame rate setting for each stream can be independent, for instance, **Stream #2** can be set **15fps** while **Stream #1** (1280x720 or below) is set to **5fps**.

STREAM #1	STREAM #2		STREAM #3
	640x480	320x240	640X480 (fixed)
<i>1600x1200, 5~15 fps</i>			
<i>1280x720, 5~30 fps</i>	5~30 fps		1 fps
<i>800x600, 5~30 fps</i>			
<i>640x480, 5~30 fps</i>			
<i>320x240, 5~30 fps</i>	5~30 fps		

Note the resolution setting must follow the sequence: Stream1 \geq Stream2 \geq Stream3.

The Angle of View at different resolutions

The setting of Stream determines the angle of view, therefore the range of image view. The picture below presents the **3 ranges of view**, 1600x1200, 1280x720 & 800x600/640x460/320x240.




Actual Views with different resolutions


Appendix I: An example of how to set up users' own FTP servers

FTP is quite a convenient application. The users may easily set up their own FTP servers.

Following is an example of using a shareware named FileZilla. Please note that this FileZilla software's copyright belongs to Tim Kosse, <http://filezilla-project.org/>, Longvast International Co., Ltd. has no business relationship with them that users should obey the related copyright laws about using this software.

1. Download the FTP server program from <http://filezilla-project.org/download.php?type=server>. If the users also like to download the FTP client software, they may refer to <http://filezilla-project.org/> for more information.
2. Install the FTP server program, and start the program.
3. The Firewall of Windows or anti-virus software will usually try to stop such FTP server application. Please make these two programs exceptions to the firewalls accordingly.







4. Start the FTP server by clicking on the OK button. Do not change any of the original settings.



5. The users should see following screen after clicking OK button. It indicates that this FTP server is running now.






6. Type in "ipconfig" command from the Windows's command screen.




In this command screen, the IP address indicates that the address of PC when FTP server running is of "192.168.1.6".

7. Configure the user names and passwords of the users who are allowed to login into this server.








8. Set the default directory of each individual user.




9. Now the FTP server should be ready to go. The users may double-check to see if everything is alright by trying to login by using any FTP client programs with the user IDs and passwords pre-configured. In the following example we use similar Filezilla FTP Client software with the user ID of “ipcam” to login.






10. Now the FTP server is ready to store the event-triggered photo images from the network cameras. Following is a screen which the users may see on the FTP server software when a network camera is transferring photo image files to the FTP server.



11. Please note that this FTP server may also be accessed through Internet externally. Following screen shows an example of how the user may configure his broadband router to make this FTP server accessible from web externally. In case the fixed web IP of this connection is 219.86.240.235, and then the users from outside may access this FTP server from the web address of [FTP://219.86.240.235:21](ftp://219.86.240.235:21) now. In other words the user can access this FTP server by the IPs of both 192.168.1.6 or 219.86.240.234 from near end after the NAT Virtual Server is properly routed.



In terms of how to get your fixed web IP address, please refer to your Internet Service Provider for more details. Usually PPPoE is the most common protocol used for getting fixed IP, and following image shows you the setting screen of such PPPoE



ASUS RX3081



Product Name ASUS RX3081

Wizard

System Status

System

System Settings

Administrator Settings

Firmware Upgrade

Configuration Tools

System Log

WAN

LAN

NAT

Firewall

Routing

UPnP

DDNS

Logout

System Status


This page displays the LAN/WAN connection status, firmware/hardware version, and number of connected clients in your network.

WAN	
Cable/DSL	Connected
WAN IP	219.86.240.234
Subnet Mask	255.255.255.0
Gateway	211.78.222.137
Primary DNS	61.31.233.1
Secondary DNS	61.31.1.1
Connection Type	PPPoE
Connection Time	03:10:38
<input type="button" value="Connect"/>	<input type="button" value="Disconnect"/>

LAN	
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled
NAT	Enabled
Firewall	Enabled



Appendix II: How to install the VLC program

1. You may find a VLC program in the CD, and you may go to <http://www.videolan.org/vlc/> and download the latest VLC program too. In this page there is a donation field, and it is all up to the users whether they want to donate to this VideoLAN non-profit Organization. If the users do not want to make donation immediately, just ignore and click on the “Download VLC” icon to proceed with the download.



Note: this VLC shareware is proprietary of the VideoLAN non-profit Organization


2. Install VLC 1.1.10 step by step



Be sure that the “Mozilla plugin” is selected if the users need to use Firefox as web browser too, in addition to Microsoft Internet Explorer. This plugin is used for audio function.


Appendix III: How to replay the recorded video clips with VLC program

The following image is an example screen showing the video clip files which a user has collected inside a PC folder named “temp”.



Select whichever file the user want to replay. If the user has selected more than one file then the VLC will replay sequentially.

The multiple-selection is very useful, because the users may need to replay video data for a long period of time.



Note: the users may right-click and choose “full screen” mode for full-screen display.